


THIS IS AN EXAMPLE OF ADDING CENTER UNITS TO CREATE MORE LANES.
REFER TO THE PLAN AND ELEVATION DRAWING FOR DETAILS ON ARM
STAGGER AND CABINET CONFIGURATION.



THIS IS THE BASIC SPACE SAVER CONFIGURATION CONSISTING OF 2 LANES STARTING FROM LEFT TO RIGHT.

NOTE: THE ILLUSTRATION ABOVE SHOWS STANDARD 36" WIDE
ADA COMPLIANT LANES. LANES CAN VARY BETWEEN
16" - 42" WIDE.



52 RIVERSIDE ROAD
SANDY HOOK, CT 06482
PHONE: 860-410-6161

TITLE: SPACE SAVER
EXAMPLES.

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING
IS THE SOLE PROPERTY OF Q-LANE LLC. ANY
REPRODUCTION IN PART OR AS A WHOLE WITHOUT
WRITTEN PERMISSION IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
FRACTIONAL ± .000
ANGULAR ± BEND ±
2 PLACE DECIMAL ± .010
3 PLACE DECIMAL ± .005

MATERIAL	NAME	DATE
FINISH	DRAWN	
DO NOT SCALE DRAWING	CHECKED	

SIZE	PART NO.	REV
C		

SCALE: 1:48 WEIGHT: SHEET 1 OF 1